
TECHNOLOGY IN MOTION





Your windows have been fitted with a Maco Multi Vent Restrictor. The Multi Vent restrictor enables you to control the amount of fresh air entering through the window

Please follow these instructions to ensure the correct function of the Multi Vent restrictor

TECHNOLOGY IN MOTION



1. To fully open your window and release the Multi Vent restrictor:

- Unlock the Multi Vent restrictor with the allen key. Push the window into the closed position
- Depress the button on the top of the restrictor and open the window whilst holding down the button
- Once the window has cleared the frame release the button





TECHNOLOGY IN MOTION



2. To re-engage the Multi Vent restrictor:

- Push the window into the closed position
- Open the window to check that the Multi Vent restrictor has reengaged
- Close the window and re lock the Multi Vent restrictor with the allen key

Note: If the restrictor fails to reengage when the window is closed, the window may need re adjusting. Should this be required then it must be carried out by a suitably qualified person.







The Multi Vent restrictor contains a friction device to control the amount of air flow through the window.

3. To control the amount of air flow through the window:

- Tilt the window to the desired position
- Turn the allen key to increase the pressure on the friction device to hold the window in the open position
- Before closing the window release the pressure on the friction device with the allen key



Due to the design of the Multi Vent restrictor it remains engaged within both the Tilt and Turn modes of the window. It is not recommended that the Multi Vent restrictor be used in the Turn mode as it is not designated as a safety restrictor.

MACO DOOR & WINDOW HARDWARE U.K. LTD

Castle Road, Eurolink Business Centre Sittingbourne, Kent, ME10 3LY TEL: +44 (0)1795 433900 FAX: +44 (0)1795 433901 enquiry@macouk.net www.macouk.net